

Installation Instructions

Eros Sconce (Single)

Two people required for proper installation.

Wearing clean gloves will help protect wax finishes.

1. Make sure the circuit power is shut off at the electrical panel.
2. Remove the screws holding the LED Driver to the backplate. Then gently remove the Driver.
3. Pull the 110v Hot and Neutral lead wires, including a third Ground wire, from the J-Box through the hole in the backplate. Mount the backplate to the J-Box so that there is clear access to the wiring in the J-Box through the hole. Make sure the backplate is level.
4. Connect the Driver input wires to the leads using the wire nuts included. Black to Hot, White to Neutral, and Green to Ground. Tuck the wires and wire nuts back into the J-Box through the hole in the backplate. Re-mount the Driver onto the backplate making sure the input wires are safely tucked behind the Driver and the output wires are out and accessible.
5. The next step will require a second person holding the Curved LED Shade while the wiring is completed. Using the wire nuts included, twist all Red (+) LED wires together with the Red (+) Driver output wire and then all the Black (-) LED wires together with the Purple (-) Driver output wire. Carefully tuck the wires into the space below the Driver and close the fixture. Use the two included 6-32 screws to secure the top and bottom using a slotted screwdriver, being very carefully not to scratch the finish.